



Quick Installation Guide

Indoor HD IP Camera with P2P


Model: R2



"Foscam" App download

V1.2
EQR00002

Package Contents




Security Warning

- Foscam cameras and NVRs require good security practices to safeguard your privacy. You should regularly change your camera or NVR password which is 8-10 numbers, letters, symbols combination.
- You should update your camera or NVR regularly. Make sure your camera or NVR has the latest firmware installed for your specific model and better experience.


1 Hardware Introduction

Physical Description

Front panel




Rear panel




Hardware Installation

Install your camera on the ceiling or wall with the supplied mounting bracket.



Hardware Connection



1. Install wireless antenna and position upright.
2. Turn on your wireless router.
3. Connect the power adapter to the camera.

Before you continue, please note:

- Make sure your smartphone is located near the camera.
- Do not use an ethernet cable to connect the camera if you want to use a wireless connection. And the camera will play voice prompts "Ready for WiFi configuration".
- Make sure smartphone is connected to your wireless router.

Network Light Status:

Network Light	Description
Off	No Wi-Fi connection
Constant Flash	Wired connection
Flashing every 0.2 seconds	EZLink takes effect (default)
Flashing every 0.4 seconds	WPS is connecting
Slow Flash every 1.0 second	Wi-Fi connected

Please note:

The camera has a 1080P video output. Make sure you have a much smoother video experience on the smartphone. It recommends that the smartphone has the following configuration:

- IOS: system version 8.1 and above.
- Android: system version 4.1 and above, and the smartphone has a Graphics Processing Unit (GPU) function.

2 Add the IP Camera

You can add the Foscam IP Camera using a Smartphone.

1. Download the App

If you have a QR Code App on your phone, scan the code below.



Foscam

Please Note:

If you do not have a QR code app on your phone, you can simply go to the App Store or Google Play Store and search for the term "Foscam". Find the app that appears with the same icon as shown above, and download it to your device. Ensure that you download the App created by our ShenZhen Foscam Intelligent Technology Co. LTD.

2. Add the IP Camera

Run the App, and then register for a Foscam account. Once logged in, you can tap the "+" button on the App and follow the setup wizard to add your camera.

If the Wi-Fi connection is successful, the camera will play voice prompts.

Please Note:

Only with the "Foscam" APP, you can experience new features including EZLink, Online-Update, Message Push, etc. While with any third-party APP (other than "Foscam"), you do not experience these features.

If the resolution of your Foscam camera is 1080P, only the "Foscam" APP supports it.


3 Access the IP Camera

■ P2P Web Portal

After your camera has been successfully added by the app, the camera has been in a state of a Wi-Fi connection.

You can also access your Foscam camera via our P2P web portal: <https://www.myfoscam.com> on your Windows PC using Internet Explorer.

If you have registered and added the IP Camera on the Foscam App, you don't have to register again. Rather, just log in and access the camera directly via the app or browser.



■ Browser Access

As an alternative to accessing the camera via the P2P web portal, you can access the camera directly through the local network and remotely via port forwarding.

1. Please download the "Equipment Search Tool" from <http://www.foscam.com>.



Please Note:

Make sure the camera and PC are both in the same LAN.

2. Open "Equipment Search Tool".

Camera Name	IP Address	Device ID	Type
Anonymous	Http://192.168.1.105:88	00626E55AB1E	IPC

3. Double click the camera list here, and your default browser will open up to the login page.

4. When logging in for the first time, you will need to download and install the add-on.

5. After logging in, you can manage camera through the browser.

4 FAQ

Forgot Username / Password

Restore camera back to factory settings:

1. Press and hold the "Reset" button on the camera for about 10 seconds with the camera powered on, and then release.
2. Once the button is released, wait about 30 seconds. The camera will play voice prompts that reset is successful, and then automatically reboot and restore factory settings.

The username and password will be set to the default username(admin) and password(blank).

Please Note:

- After restoring to factory default settings, you need to re-configure the Wi-Fi connection. You can follow the Setup Wizard of the App to configure your Wi-Fi connection again.
- If your device fails to connect to the Wi-Fi using the Setup Wizard, you may setup Wi-Fi manually after connecting the camera via a wired connection. Please refer to the User Manual on the Foscam website at <http://www.foscam.com>.

5 Technical Support

If you have problems with your Foscam IP Camera, please contact the Foscam reseller you purchased from, or you can e-mail the Foscam headquarter technical support team: tech@foscam.com.

Your valuable comments and suggestions on improving Foscam products are welcomed!

FOSCAM[®]



CE Certificate Website:

<http://www.foscam.com/company/ce-certificate.html>

ShenZhen Foscam Intelligent Technology Co., Ltd

www.foscam.com